

Teledyne DALSA
Vision Solutions

MICROCALIBIR

COMPACT UNCOOLED
LWIR CORES

 **TELEDYNE**



03-032-25006-00

QUICK-START GUIDE

1. Gently plug-in USB interface (IF) board to the back of the camera core.
2. Install the two Phillips screws at the back of the USB IF board.

Note: Do not fully tighten one screw then the other as this may cause torsion and damage the board.

- a. First apply light torque to both screws to ensure the board is properly set in place.
 - b. Then apply slightly more torque to tighten.
3. Plug the USB-C cable into the USB-C socket on the board.

4. The camera should appear as a new USB mass-storage device (listed as the serial#). The camera user manual is available on this new drive.

FOR MORE INFORMATION CONTACT US AT
<https://www.teledynedalsa.com/en/support/request-product-support/>

WARNING: Unit is not ESD safe—handle with care and avoid touching components or PCBs if possible. Do not disconnect USB back-end from unit while powered on.

